



Xede Wiring Diagram – 2007 Landcruiser 70 series 1VD-FTV (Diesel D4D)

Wiring Details:

Note: Connectors are drawn as seen from the wire side.

<i>XEDE</i> Configuration:	S
<i>XEDE</i> Revisions:	All
<i>XEDE</i> Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page

View from back of ECU connectors
(wire view)

23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	11	10	9	8	7	6	5	4	3	2	1
46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	19	18	17	16	15	14	13	12	22	21	20
86	85	84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	30	29	28	27	26	25	24	23	33	32	31
109	108	107	106	105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	41	40	39	38	37	36	35	34	33	32	31
						126	125	124	123	122	121	120	119	118	117	116	115	114	113	112	111	110	49	48	47	46	45	44	43	42	52	51	50
																							60	59	58	57	56	55	54	53	52	51	50

* MUST BE CONNECTED TO CHASSIS GROUND AND NOT TO SENSOR GROUND. USE AN EYE TERMINAL TO ATTACH TO A CHASSIS BOLT.
 ** Red wire in 3 core shielded cable. DO NOT terminate the shield wire in the 3 core cable
 *** All unspecified wires can remain insulated and unterminated

