



Xede Wiring Diagram – 03/2009 Mazda 3 MPS

Wiring Details:

Note: Connectors are drawn as seen from the wire side.

<i>XEDE</i> Configuration:	H
<i>XEDE</i> Revisions:	All
<i>XEDE</i> Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page

2BE	2BA	2AW	2AS	2AD	2AK	2AC	2AG	2Y	2U	2Q	2M	2I	2E	2A
2BF	2BB	2AX	2AT	2AP	2AL	2AH	2AD	2Z	2V	2R	2N	2J	2F	2B
2BG	2BC	2AY	2AU	2AQ	2AK	2AJ	2AE	2AA	2W	2S	2D	2K	2G	2C
2BH	2BD	2AZ	2AV	2AR	2AN	2AM	2AF	2AB	2K	2T	2P	2L	2H	2D

1BE	1BA	1AW	1AS	1AD	1AK	1AC	1AD	1Y	1U	1Q	1M	1I	1E	1A
1BF	1BB	1AX	1AT	1AP	1AL	1AH	1AD	1Z	1V	1R	1N	1J	1F	1B
1BG	1BC	1AY	1AU	1AQ	1AK	1AJ	1AE	1AA	1W	1S	1D	1K	1G	1C
1BH	1BD	1AZ	1AV	1AR	1AN	1AM	1AF	1AB	1X	1T	1P	1L	1H	1D

* ONE OR BOTH OF THE CHASSIS GROUNDS MUST BE CONNECTED IF ANY OF THE FOLLOWING XEDE FEATURES ARE BEING USED:

- WATER SPRAY
- BOOST CONTROL
- AUXILIARY INJECTOR DRIVE

➔ Red wire in 3 core shielded cable. DO NOT terminate the shield wire in the 3 core cable

