

## Xede Wiring Diagram – 2005 Mitsubishi 380 3.8L V6

### Wiring Details:

Note: Connectors are drawn as seen from the wire side.

<b>XEDE</b> Configuration:	M
<b>XEDE</b> Revisions:	All
<b>XEDE</b> Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page

ECU  
View from back of connectors  
(wire view)

\* ONE OR BOTH OF THE CHASSIS GROUNDS MUST BE CONNECTED IF ANY OF THE FOLLOWING XEDE FEATURES ARE BEING USED:

- WATER SPRAY
- BOOST CONTROL
- AUXILIARY INJECTOR DRIVE

\*\* Red wire in 3 core shielded cable. DO NOT terminate the shield wire in the 3 core cable

46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	5	6	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94
31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	3	4	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	1	2	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	1	2	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28

