



Xede Wiring Diagram – 2007 Mazda BT50 3.0L TDCI

Wiring Details:

Note: Connectors are drawn as seen from the wire side.

XEDE Configuration:	S
XEDE Revisions:	All
XEDE Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page

View from back of ECU connectors
(wire view)

* MUST BE CONNECTED TO CHASSIS GROUND AND NOT TO SENSOR GROUND.
USE AN EYE TERMINAL TO ATTACH TO A CHASSIS BOLT.

** Red wire in 3 core shielded cable. DO NOT terminate the shield wire in the 3 core cable

*** All unspecified wires can remain insulated and unterminated

124	123	122	121	120	119	118	117	116	115	114	113	112	111	110	109	108	107	106	105	104	103	102	101	219	218	217	216	215	214	213	212	211	210	209	208	207	202	201
148	147	146	145	144	143	142	141	140	139	138	137	136	135	134	133	132	131	130	129	128	127	126	125	232	231	230	229	228	227	226	225	224	223	222	221	220	204	203
172	171	170	169	168	167	166	165	164	163	162	161	160	159	158	157	156	155	154	153	152	151	150	149	245	244	243	242	241	240	239	238	237	236	235	234	233	206	205
196	195	194	193	192	191	190	189	188	187	186	185	184	183	182	181	180	179	178	177	176	175	174	173	258	257	256	255	254	253	252	251	250	249	248	247	246		

